


Montážní návod
Installation manual




PC108WR



[01] x 1




[02] x 1



[03] x 1




[04] x 1



[05] x 1




[06] x 1



[07] x 1



[08] x 1



[09] x 2




[10] x 2



[11] x 2



[12] x 2



[13] x 1



[14] x 2
(Ø 4 x 50 mm)




[15] x 2




[16] x 2



[17] x 2




[18] x 2



[19] x 1




[20] x 2




[21] x 2




[22] x 2
(Ø 6 x 60 mm)




[23] x 2



[24] x 2




[25] x 2
(Ø 5 x 50 mm)



[26] x 2




[27] x 1




[28] x 1



[29] x 1



[30] x 1




[31] x 1



[32] x 1




01




[27]



[28]



[29]



02



[02]



[03]



[09]



[10]




[11]





[12]




[13]




03



[01]




[04]





[05]


04




05




06





07





08






09




10




11



12



13



14

